

# Maintenance Instructions LN Series Needle Valve



#### WARNING

Before disassembly be sure to provide a clean area to keep components for reuse.

### **Tools Required**

	Tool	Description	
Vise		For holding body/bonnet during assembly	
Torque wrench	P. Commercial Control of the Control	Size depends on necessary torque requirement for assembly	
Christo-Lube MCG 130 lube		Unless special lube is designated	

Size	LNG/LNBP LNBB		LN8	HLN4	HLN6	Part
	LN4	LN6				
Wrench	5/8 in.	3/4 in.	1 1/8 in.	3/4 in.	1-1/8 in.	Bonnet
						Packing Nut
						Panel Nut
	5/16 in.	3/8 in.	5/8 in.	5/16 in.	3/8 in.	Packing Bolt
Hex	7/64 in.	5/32 in.	3/16 in.	5/32 in.	3/16 in.	Socket Screw
	3/32 in.	1/8 in.	5/32 in.	3/32 in.	1/8 in.	Set Screw

# **Disassembly**

1. Rotate the handle so that the valve is in the fully open position.



2. Use an Allen wrench to loosen the set screw in the handle.



3. Lift the handle over the upper stem.



4. Loosen the socket set screw with an Allen wrench and remove from the bonnet lock. The bonnet lock will now be free to lift up over the bonnet.



5. Use a wrench to remove the bonnet assembly from the body. Discard the bonnet assembly. Disassembly is now complete.



## **Assembly**

6. Lubricate the bonnet threads and sealing surface with the provided Christo-Lube MCG 130. Use a torque wrench to tighten the bonnet into the body using the toque chart below. (Make sure that the stem is in the open position before tightening into the body.)



7. Place the bonnet lock back over the body and align slot with the threaded socket screw hole.



8. Slide the handle over the upper stem so that the threaded hole in the handle aligns with the set screw point on the upper stem. Insert the set screw into the handles threaded hole and tighten with an Allen wrench until "snug".



9. Test the opening and closing of the valve. The assembly is now complete.



## **Torque**

LN Valve			Torque Required		
			in - lb	ft - Ib	
	LNBB	LN4	150	13	
LNG/LNBP		LN6	400	34	
		LN8	475	40	
		HLN4	375	32	
		HLN6	500	42	

www.mySSPusa.com LNLPMI-20170411-A